



Channel Frequency Chart (MHz)

Channel	Frequency	Channel	Frequency	Channel	Frequency
01	72.05	14	72.7	26	75.4
02	72.1	15	72.75	27	75.45
03	72.15	16	72.8	28	75.5
04	72.2	17	72.85	29	75.55
05	72.25	18	72.9	30	75.6
06	72.3	19	72.95	31	75.65
07	72.35	20	74.65	32	75.7
08	72.4	21	74.7	33	75.75
09	72.45	22	74.75	34	75.8
10	72.5	23	75.25	35	75.85
11	72.55	24	75.3	36	75.9
12	72.6	25	75.35	37	75.95
13	72.65				

